

TOMOS

SPARE
PARTS
CATALOGUE



SUPER TOM

www.agmoto.hr
tel: 01-584-123


2001

TOMOS

CRANKCASE, CYLINDER, PISTON


A

230 611 - engine
227 331 - gasket set



CRANKSHAFT, CLUTCH


B



A - 1st speed clutch
 B - 2nd speed clutch

COUNTERSCHAFT, MAINSHAFT


C



△ 222 209 (section D)



STARTER ASSEMBLY

D



MAGNETO ASSEMBLY


E



CARBURETOR, INTAKE MANIFOLD


F

● 230 260




FUEL TANK, SEAT, EXHAUST SYSTEM

G




FRAME, SWING ARM


H



COVERS, FENDERS, DECALS



www.agmoto.hr
tel 051-584-123




230 604 DECALS kpl

FRONT FORKS

J


▲ 227 470 - set of bearings



HANDLEBAR, CONTROLS, CABLES

K


- 229 551 - throttle assy.
- 229 552 - rear brake lever assy.



FRONT MAGWHEEL

L


● 230 613



REAR MAGWHEEL

M

● 230 615



www.agricraft
tel 051-544123

INDEX

Part. No	Description	Section	Part. No	Description	Section
25205	SCREW M6x80	G	206499	CHAIN 91 ROLLERS	M
25210	SCREW M7x30	M	206827	NUT M11x1	L, M
25221	SCREW M8x18	J	206846	DISTANCE BUSH	L, M
25569	SCREW M10x40	H	208201	STUD BOLT M6x24	A
26042	SCREW M8x1x75	A	208449	BRAKE CAM	L, M
26083	SCREW M12x1.25x120	H	209002	SPRING WASHER	B
26311	SCREW M6x10	A	209013	CLUTCH SPRING	B
26327	SCREW M10x25	H	209039	BRAKE STRIP	B
26331	SCREW M12x25	J	209048	RETURN SPRING	D
26561	SCREW M6x16	J	209062	PROTECTIVE WASHER	C
26566	SCREW M5x20	A	209063	ROLLER D5x8	C
26582	SCREW M6x65	A	209073	WASHER 0.3 - if required	B
26657	SCREW M5x12	E	209075	WASHER 0.2 - if required	C
27057	SCREW M4x20	F	209076	WASHER 0.5 - if required	C
27064	SCREW M5x10	F	209077	DISTANCE BUSH	C
27066	SCREW M5x16	E	209078	CHAIN SPROCKET Z26	C
27079	SCREW M6x16	K	209079	PROTECTIVE PLATE	C
27083	SCREW M6x30	F	209080	NUT M22x1	C
27264	SCREW M6x10	A	209087	WASHER 0.2 - if required	D
27265	SCREW M6x12	I	209119	WASHER 0.5 - if required	B
27268	SCREW M6x16	I	209141	BEARING BUSH	H
30020	NUT M6	G	209144	DISTANCE TUBE	H
30040	NUT M6	G, I	209212	CHAIN TENSION ADJUSTER RH	M
30042	NUT M10x5	H	209249	NUT M11x1	L, M
30048	NUT M5	K	209254	WASHER D12xD18x1.5	L, M
30049	NUT M8x1	A	209253	DISTANCE BUSH	L
31073	NUT M4	F	209263	DISTANCE BUSH	L, M
31074	NUT M5	E	209277	NUT M11x1	L, M
31075	NUT M6	F, G, L, M	209566	RATCHET BLOCK	D
31076	NUT M7	A, D, M	210175	RUBBER PROTECTOR	E
31126	NUT M12x1.25	H	211977	SPARK PLUG CAP	E
31230	NUT M6x5	L, M	212959	SHIM 0.2	B
31845	WASHER B6	G, J	213652	SCREW	K
31848	WASHER B10	H	215487	NUT M10x1	B, E
31867	WASHER A5	E	217078	BRAKE LEVER	L
31925	WASHER A6	G, I	217085	CAP	L, M
31930	WASHER 4	F	217096	PROTECTIVE WASHER	M
31931	WASHER 5	A	217437	GRIP LH	K
31932	WASHER 6	L, M	217438	GRIP RH	K
31933	WASHER 8	A, J	217582	CHAIN	D
31935	WASHER 12	H	217584	CHAIN SPROCKET Z25	D
31978	WASHER B10	B	217753	WASHER D6.5xD18x2	I
31997	WASHER A12	H	217903	DUST PROTECTOR	J
32039	WIRE CIRCLIP	A	219211	RUBBER GUIDE	J
32073	CIRCLIP	D	219223	UPPER PLUG	J
32077	CIRCLIP	C	219224	LOWER PLUG	J
32083	CIRCLIP	B	219225	SPRING	J
35031	BALL BEARING	C	219226	RUBBER BUSH	J
35037	BALL BEARING	C	219227	RUBBER ABSORBER	J
35070	BALL BEARING	B	219254	SUPPORTING TUBE	J
35072	BALL BEARING	C	219349	STEERING NUT	J
35202	BALL BEARING	B	219374	JUNCTION SLEEVE	F
35502	NEEDLE BEARING	C	219375	CLAMP	F
35503	NEEDLE BEARING	C	219376	AIR FILTER	F
35548	NEEDLE BEARING	B	219580	THROTTLE SLIDE	F
35554	ROLLER CLUTCH	B	219582	FLOAT	F
35600	BEARING	C	219583	GASKET	F
36555	GASKET	B	219584	FUEL CONNECTION	F
36620	GASKET	C	219585	FUEL FILTER	F
37050	PIN	J	219587	ADJUSTING CREW	F
44154	WASHER A7	A	219588	SPRING	F
44157	WASHER A12	J	219589	FLOAT VALVE	F
44225	BALL BEARING	L, M	219590	GASKET	F
44472	TUBE	J	219591	SPRING	F
44511	SPARK PLUG	A	219592	SCREW	F
44528	CABLE	E	219593	FLOAT PIN	F
44531	FUEL TUBE	G	219594	GASKET	F
44535	BALL	J	219595	FLOAT CHAMBER	F
44835	WOODRUFF KEY	C	219596	COVER	F
44838	GASKET	B	219598	SCREW	F
200048	ROLLER D3x4	E	219623	CONNECTION	F
200141	NUT M14x1	C			
200175	SHIM (0.5 mm)	D			
200294	RUBBER	A			
200609	SPRING	H			
200714	STEERING BEARING CONE	J			
200717	NUT	J			
201197	NIPPLE	K			
201487	LEVER RUBBER	D			
202723	BUSH	D			
202726	PIN	D			
202727	WASHER D7.4xD17x2	D			
205386	SCREW M7x115	A			
205702	THRUST WASHER 2.0	D			
206391	WASHER 1.0 - if required	D			

www.agmto.hr
tel 051-58-13

INDEX

Part. No	Description	Section	Part. No	Description	Section
219624	RUBBER BUSH	F	227501	GUDGEON PIN	A
219625	ADJUSTING SCREW	F	227649	THROTTLE CABLE	K
219626	NUT	F	227724	KICK START LEVER	D
219780	SEAL RING	F	227758	PISTON RING	A
219786	DISTANCE WASHER	L, M	229399	RUBBER RING	J
219791	BRAKE CAM	L, M	229402	CYLINDER WITH PISTON	A
219799	BRAKE LEVER	M	229449	SUPPORTING TUBE	J
219806	BRAKE SHOE	L, M	229551	THROTTLE ASSY.	K
219807	SPRING	L, M	229552	BRAKE LEVER	K
219809	BEARING (CAGE)	L, M	229553	LEVER CLAMP RH	K
219871	PIN	F	229554	LEVER CLAMP LH	K
219872	SPRING	F	229556	ADJUSTING SCREW	K
219873	LEVER	F	229827	MAIN JET	F
219874	SPRING	F	229919	WASHER	E
219875	SET OF GASKET	F	230169	LOWER YOKE	J
221405	KICK START LEVER	D	230172	SEALING WASHER A6x12	A
221406	HUB	D	230173	SCREW A8x14	A
222041	PISTON RING	A	230182	RING	L, M
222087	SIDE COVER GASKET	A	230183	REAR AXLE	M
222098	CENTERCASE GASKET	A	230184	STEERING BEARING CONE	L, M
222145	FUEL TAP	G	230186	REAR WHEEL	M
222206	COUNTERSHAFT	C	230187	CHAIN SPROCKET Z27	M
222209	STARTING CAGE	C, D	230189	DISTANCE BUSH	M
222238	REED VALVE	A	230191	BRAKE PLATE REAR	M
222600	BRAKE LEVER LH	K	230192	BRAKE PLATE FRONT	L
222601	BRAKE LEVER RH	K	230193	FRONT AXLE	L
222605	SPRING LH	K	230194	DISTANCE BUSH	L
222606	SPRING RH	K	230195	FRONT WHEEL	L
222608	THROTTLE TWIST GRIP	K	230260	CARBURETOR	F
222652	REDUCING TUBE 30/13.5	F	230282	GASKET	B
222807	PROTECTIVE COVER	J	230285	GASKET	B
222808	WASHER D26.2xD36x0.7	J	230327	MAGNETO ASSEMBLY	E
222848	WASHER D26.2xD36x2	J	230328	BASE PLATE	E
222927	STRIP 180	F, J, K	230329	FLYWHEEL	E
223025	LEVER	F	230401	INTAKE TUBE 23x27	F
223026	CHOKE LEVER	F	230403	EXHAUST PIPE	G
223027	SPRING	F	230405	FRONT WHEEL	L
223078	MUDGUARD STAY	J	230406	REAR WHEEL	M
223112	CHAIN TENSIONER LH	M	230409	FRAME	H
223121	COUNTERSHAFT SPRING	C	230410	BRAKE CABLE FRONT	K
223155	BEARING CUP TOP	J	230411	BRAKE CABLE REAR	K
223157	BEARING CUP BOTTOM	J	230413	FUEL TANK	G
223421	CRANKSHAFT	B	230414	FUEL TANK COVER	G
223423	GEAR WITH DRUMS	B	230417	FUEL VALVE	G
223429	CLUTCH HUB	B	230418	SEAT	G
223432	CLUTCH SHOE WITH	B	230419	SET OF DECALS	I
223434	PIN	B	230421	SET OF DECALS	I
223435	DRIVING GEAR	B	230423	LEVER	I
223440	CONTERING BUSH D9.8x16	A	230426	REAR FORK	H
223447	STARTER SHAFT	D	230429	PROP STAND	H
223448	SPACER	D	230432	FOOTREST	H
223456	MAINSHAFT	C	230435	FRONT MUDGUARD	I
223458	COUNTERSHAFT	C	230436	MUDGUARD HOLDER	I
223461	2nd SPEED GEAR	C	230438	REAR MUDGUARD	I
223463	DRUM	C	230439	ADJUSTING SCREW	L, M
223466	CYLINDER HEAD	A	230441	INNER TUBE	L, M
223468	THRUST WASHER	B	230442	TYRE 3.00-10 CROSS	L, M
223469	THRUST WASHER	C	230445	RIGHT SHIELD	I
223470	BEARING BUSH	B	230446	LEFT SHIELD	I
223473	SPRING	D	230459	RUBBER	G
223562	CLUTCH SHOE	B	230489	SCHOCK ABSORBER	H
223602	RUBBER COVER	D	230494	PLATE HOLDER	J
223603	INTAKE ELBOW	A	230496	PLATE	I
223680	SHOCK ABSORBER	H	230497	PROTECTOR	K
223747	PISTON	A	230503	SLIDING TUBE RH	J
223748	REED VALVE GASKET	A	230505	SLIDING TUBE LH	J
223796	CYLINDER GASKET	A	230508	BRAKE PLATE FRONT	L
224056	CLAMP	G	230509	REAR AXLE	L
227018	CLUTCH 1CPL	B	230511	DISTANCE BUSH	L
227019	CLUTCH 2CPL	B			
227149	EXHAUST FLANGE GASKET	G			
227194	SPROCKET 1st GEAR	C			
227308	CLAMP	J			
227324	SEAL RING	F			
227326	BUSH	F			
227328	CHOKE LEVER	F			
227331	SET OF GASKETS	A			
227332	CRANKCASE	A			
227334	PISTON 1st OVERSIZE	A			
227450	WASHER D11.1xD20x2	L, M			
227470	SET OF HANDLEBAR BEARINGS	J			

www.agmco.com
tel 051-584-1234

INDEX

Part. No	Description	Section
230514	BRAKE PLATE REAR	M
230515	REAR AXLE	M
230516	DISTANCE BUSH	M
230604	DECALS	J
230611	ENGINE	A
230612	ENGINE COVER LH	A
230613	FRONT WHEEL	L
230614	FRONT WHEEL	L
230615	REAR WHEEL	M
230616	REAR WHEEL	M
230627	ELECTRONIC	E
231015	RUBBER	A
232548	HANDLEBAR CARRIER	J
240225	DISTANCE BUSH	M
242001	HANDLEBAR	K
242005	TOP FDRK LUG	J
260216	CATCH PIN	D
260217	SPRING	D

www.agmoto.hr
tel 051-584-123